

Project Name:		
Date:	Note:	

















Optional Accessories







Sensor



Features

- UL&DLC Listed. Suitable for damp locations. More than 50%
- energy savings compared to traditional fluorescent fixtures.
- Reduce SKUs with Power Select and Color Select switches, allowing quick selection of 5 lumen outputs and 5 color temperatures ononemodel.
- Easy installation for new construction and retrofits. Fits standard T-grid ceilings for recessed installation and supports surface or suspended mounting with optional accessories.
- Optional plug-and-play motion and daylight harvesting sensors for enhanced energy savings.

			Specific	ations			
Model No.	ESS-PB2-1X4-40W-H- TWCCT	ESS-PB2-2X2-40W-H- TWCCT	ESS-PB2-2X4-72W-H- TWCCT	ESS-PB2-2X2-40W-H- TW CCT(X X)	ESS-PB2-2X4-72W-H-TW CCT(X X)	ESS-PB2-2X2-40W-H- TWCCT (EM)	ESS-PB2-2X4-72W-H- TWCCT(EM)
Size	1'x4'	2'x2'	2'x4'	2'x2'	2'x4'	2'x2'	2'x4'
Feature		LED Panel Backlit		LED Panel Backlit	: With Sensor Base	LED Pane With Emergency I	
Wattage	20W /25W /3	0W /35W /40W	30W/40W/50W /60W/72W	20W/25W/30W/35W/ 40W	30W/40W/50W /60W/72W	20W/25W/30W/35W /40W	30W/40W/50W /60W/72W
DLC ID	P2U165MP	S-HRQP59	S-FL8HZW	S-HRQP59	S-FL8HZW	S-HRQP59	S-FL8HZW
Lumens	5200 L	M@40W	9360 LM@72W	5200LM @40W	9360LM @72W	5200LM @40W	9360LM @72W
Rated Input Voltage(V)				120-277V			
Dimming				0-10V Dimmable			
CCT			,	30K/35K/40K/50K/65K Se	lectable		
CRI				≥80			
Power Factor				>0.9			
Beam Angle (°)				110°			
Lumen Efficiency				130 Lm/W			
Working Temperature			-13	3°F~ +113°F/-25°C~ +45°	С		
Environment Location				IP 20 – Indoor Only	1	С	CT 3CCT
Lifespan			Lumen Mainte	nance over 70% @	50,000+ Hours		
Lampshell				White			
PC/ Master Pack				2			

MODEL: LED BACK-LIT PANEL ADDRESS: 8 The green, Dover, Delaware

PHONE: 574-505-6555



Project Name:		
Date:	Note:	


Ordering Code Definition

Example: ESS-PB2-1X4-40W-H-TWCCT


Company Code	Product	Size	Power:	н	TW	ССТ	Suffix
		1'x 4'	000000000000000000000000000000000000000				XX: With Sensor Base
ESS	PB2: LED Backlit Panel	2'x2'	20W/25W/30W/35W/40W	120-277V	Tunable Wattage	30K / 35K / 40K / 50K / 65K	MS: With motion Sensor EM: with Emergency Back-
		2'x 4'	30W/40W/50W/60W/72W			7 00117 0011	up Battery

Product Dimensions


2x4 Front View




1x4 Front View



2x2 Front View



Side View



1.58" 40 mm

			Package Ir	formation			
Model NO	ESS-PB2-1X4- 40W-H-TWCCT	ESS-PB2-2X2- 40W-H-TWCCT	ESS-PB2-2X4- 72W-H-TWCCT	ESS-PB2-2X2- 40W-H-TWCCT (XX)	ESS-PB2-2X4- 72W-H-TWCCT (XX)	ESS-PB2-2X2- 40W-H-TWCCT (EM)	ESS-PB2-2X4- 72W-H-TWCCT (EM)
Package Size	1265X95X360mm 49.8"x3.74"x14.17"	655X95X660mm 25.79"x3.74"x25.98"	1265X95X660mm 49.8"x3.74"x25.98"	655X95X660mm 25.79"x3.74"x25.98"	1265X95X660mm 49.8"x3.74"x25.98"	655X95X660mm 25.79"x3.74"x25.98"	1265X95X660mm 49.8"x3.74"x25.98"
Package Weight	4.45kg / 9.81LBS	4.71kg / 10.38LBS	9.22kg / 22.33LBS	4.71kg / 10.38LBS	9.22kg/ 20.33LBS	5.5kg/ 12.13LBS	10.4kg / 22.93LBS
Package CBM	0.043263	0.041069	0.079316	0.041069	0.079316	0.041069	0.079316
40HQ Capacity (PCS)	~2680	~2820	~1460	~2820	~1460	~2820	~1460
40HQ Capacity (PCS)	~3140	~3310	~1710	~3310	~1710	~3310	~1710
40HQ Capacity (PCS)	~3600	~3790	~1960	~3790	~1960	~3790	~1960

MODEL: LED BACK-LIT PANEL ADDRESS: 8 The green , Dover, Delaware

PHONE: 574-505-6555

Eaglesolarsupply




Project Name: _		
Date:	Note:	


Photometric Report

2X4 50W LED BACKLIT PANEL

LUMINOUS INTENSITY DISTRIBUTION DIAGRAM



VERTICAL EQUILUMINOUS CURVE



Installation

Read Before Installation:

Always follow basic safety precautions when installing. These include:

- 1. Carefully read all instructions prior to installation.
- 2. Professional installation and maintenance are required for this LED panel.
- 3.Use only a dedicated external LED driver to power the LED panel.
- 4. Disconnect the power supply before installation or maintenance.
- 5. Ensure all wires are properly connected before powering on the device.
- 6. Provide sufficient space for heat dissipation.
- 7. Never cover the luminaire with heat insulation mats or slim layer materials.
- 8.IP40 rating is for indoor use only (not suitable for damp locations); IP54 rating is for indoor damp locations.
- 9.Operating temperature: -10°C to +45°C. Avoid direct sunlight.
- 10. Store in cool, dry conditions.

Installation Procedure

WARNING:

- Switch off before installation.
- Switch on only after complete installation and examination of the circuit.





A

CAUTION:


Make sure that the mounting surface or structural member used for installation can support the weight of LED Panel.

PHONE: 574-505-6555




Project Name:		
Date:	Note:	_

Wiring Guide



(1) Remove the knock-down hole on box by screwdriver (Part A), Remove screw and take out the driver cover (Part B)




(3) Cover the driver box and tighten it with a screwdriver, finish connection.

JUNCTION BOX DIM-(Grey) AC-L (Black AC-L (Black) AC-N (White) metal tube

- (2) Connect the wire as the picture showing.
- Thisknock-out at side surface is notpermitted for branch circuitentry into the luminaire.


For the product with Slide Switch of CCT or power selection, please select the CCT or power needed before installation. (Ignore these steps if without the function)



Lamp inspection before installation: please adjust the lamp with below steps before installation: 1. Press the oposite angles at the same time;

2. Press another two oposite angles at the same time, make sure the four angles are flat, then start the installation.

Take out the lamp from the box and put it in a flat table, if the lamp upwarps,




ADDRESS: 8 The green, Dover, Delaware **PHONE**: 574-505-6555

22X4PX Watt




Project Name:		_
Date:	Note:	_

Recessed Mounted



① Remove the ceiling plaster slab.




② Feed the main AC wire in driver terminal block respectively, connect the panel light and driver.


③ Fix the panel light into plaster ceiling.

4 Make sure the led panel light is firmly fixed, turn on the power.







Suspended Mounted




① Fix the anchor into target place on the ceiling.




② Fix the installation mount on the ceiling with plastic anchor.



③ Hang the panel to ceiling with suspended installation kits,adjust the length of steel wires.






Eaglesolarsupply MODEL: LED BACK-LIT PANEL ADDRESS: 8 The green , Dover, Delaware PHONE: 574-505-6555 https://eaglesolarsupply.com




Project Name:		_
Date:	Note:	_

Surface Mounted



① Assemble the surface mounted frame and fix by screws.

② knock the plastic anchor into ceiling, fix the surface mounted frame on the ceiling by screws.




④ Fix the side frame back by screw.


③ Unscrew the side frame then take out, connect the panel light to power supply, insert the panel light into the frame.



Make sure the frame and panel light are firmly fixed, turn on the power.







Warning:

Input wire diameter ≥0.75mm²;

Product modification and improper installation are not valid for warranty!


ADDRESS: 8 The green, Dover, Delaware **PHONE**: 574-505-6555



Project Name:		
Date:	Note:	

Sensor Light Instruction

SENSOR BASE





SENSOR

PIR Occupancy Bi-level

& Daylight Harvesting Sensor





WARNING


NOTE: Warm up time is 40seconds. After the sensor connects input power first time, the light will keep on 40seconds, then go to dimming to work normally.

NOTE: Factory Default Setting: Task light level:100%, Occupied timeout: 5min, Timeout light level: 20%, Prolonged: 30minitues.

NOTE: Any setting changed by remote control, the led light that sensor connect will on/off as confirm.

Dimming Function

This function inside the motion sensor to achieve tri-level control, for some areas which require a light change notice before switch-off. The sensor offers 3 levels of light: 100%-->dimmed light (natural light is insufficient) --> off; and 2 periods of selectable waiting time: motion hold-time and stand-by period; Selectable daylight threshold and freedom of detection area.



light does not switch on when presence is detected.



With sufficient natural light, the With insufficient natural light, the sensor switches on the light automatically when presence is detected.



After hold-time, the light dims to stand-by ievel if the surrounding natural light is below the daylight threshold.



Light switches off automatically after the stand-by period elapses.

https://eaglesolarsupply.com



Project Name:	
Date:	_ Note:

Emergency LED Driver Installation

CAUTION:

- 1 The Emergency LED driver must connect to 0-10V dimming wires(DIM+,DIM-) of the luminaire if the LED
- When dimming to minimum, the LED luminaire power must be less than emergency driver's power.
- ③ In emergency mode, double click test switch to turn off emergency state during storage and transportation.

Model: BLD-YT08H-XXX

Input Voltage: 100-347Vac, 50/60Hz

Ambient Temperature: 5°C ~ 50°C (41°F ~ 122°F)

Input Current: ≤ 100mA

(1) ≤ 60W (0-10V dimming luminaire) Application:

Input Power: 6W Max.

(2) ≤ 8W (non-dimming luminaire)

Output Voltage: 170Vdc Output Power: 8W


Product includes the following components:

PARTS	QUANTITY
LED Emergency Driver	1
Charging Indicator/Testing Button	1
Charging Indicator/Testing Button Wall Cover	1
Instruction Sheet	1



Dimension:


17.7"X1.26"X0.83" (450X32X21mm)



Wiring Diagram:

Eaglesolarsupply

1. For luminaire with 0-10V LED driver and using 0-10V dimmer (* LED DRIVER INPUT POWER NOT GREATER THAN 60W) Emergency Inverter Dim+ (Blue), Driver Dim- (Yellow) has to connect with LED driver DIM+ and DIM



MODEL: LED BACK-LIT PANEL ADDRESS: 8 The green, Dover, Delaware

PHONE: 574-505-6555